



CURLIN PUMP QUICK GUIDE FOR CONTINUOUS CHEMOTHERAPY

PROCEDURE:

1. Turn the pump on by pressing the **ON/OFF** key.
2. A series of screens will automatically appear. One of the screens will display a bar that represents the power remaining in the batteries. Replace the batteries daily and as needed. (See Curlin Pump battery replacement steps below).
3. A black bar or cursor on one of the rows of text will be seen on the screen. To move the cursor from one field to another, use the blue up and down arrow keys.
4. The screens which require you to press the **YES** key are as follows:
 - After turning the pump on, the first screen that appears has a cursor on the **PROGRAM** field. Press the **YES** key.
 - The second screen should read **RESUME, REPEAT RX, or NEW PROGRAM**.
 - Since your infusion was previously started by the nurse, you will move the cursor to the **RESUME** row of text and then press the **YES** key.
 - Once you select **RESUME**, the next screen will appear displaying **RUN to START, NO to REVIEW, OPTIONS or PRIME**. Press the **RUN/PAUSE** key.
 - A message will appear on the screen to verify the proper tubing is used. Press “yes” to start the infusion.

NOTE:

- When your therapy is infusing, a number of information screens will display and the green status light blinks.
- Green light blinks when the pump is running.
- Yellow light blinks when the pump is paused.
- Red light blinks when there is an alarm. If alarm states “empty battery” press the **PAUSE** key then turn the pump off by pressing the **ON/OFF** key. Follow the directions for Curlin Pump battery replacement” below. When the battery change is complete, turn pump back on and follow the above directions.

CURLIN PUMP BATTERY REPLACEMENT:

SUPPLIES:

- (2) “C” batteries (Change every day and as needed)
- Coin (if needed)





CURLIN PUMP QUICK GUIDE FOR CONTINUOUS CHEMOTHERAPY

1. When changing batteries, press the **PAUSE** key, then turn the pump off by pressing the **ON/OFF** key.
2. Open the battery compartment door by depressing the recessed release pin using a small coin. Do not use a screwdriver or other sharp object at any time when changing pump batteries.
3. Slide the battery door down and remove it from the pump.
4. Remove the batteries from the pump.
5. Install two new “C” size batteries by depressing the coil spring with the bottom end of the battery and sliding the top of the battery into place.
6. Both positive poles of the batteries should be at the top of the battery compartment.
7. Slide the battery door compartment back to its closed position. Slide the gray tab to lock. * Pumps that have a slide latch need to be slide latched into locked position.
8. Turn pump on. Select program. Select **RESUME** (which is highlighted). Press **RUN** to start.

WARNING: If the batteries are removed from the bottom end first, damage to the springs within the battery case may result. When the springs become damaged, the batteries may overheat.

If the batteries or the pump become excessively warm to touch, do not attempt to remove the batteries. Set pump aside and contact Chartwell immediately.

Revised 3/2014

