

## CADD SOLIS PUMP DISPOSABLE BATTERY CHANGE

**Note:** If the yellow and green light on the top left corner of the pump starts blinking, and a “**Battery Depleted**” or “**Battery Low**” message appears on the display screen, you should change the batteries. Use 4-AA (non-rechargeable) alkaline batteries.

### SUPPLIES NEEDED:

- 4-AA batteries
- CADD Solis Pump

### PROCEDURE:

1. Stop the CADD Solis pump by pressing START/STOP button on keypad.
2. When you see “**Stop Pump?**”, press “**Yes**” on keypad.
3. Press and hold the power button on the right-hand side of pump. Pump asks “**Power down?**” Press “**Yes**” on keypad.
4. To open the battery door (found at the top of pump), turn the indented notch on the door counterclockwise (to the left). You can use your fingers, the pump key or a coin.
5. Remove old AA batteries.
6. While holding the pump at an angle, place four new AA batteries in the pump.
  - Start at the bottom and work your way up.
  - Match the (+) and (-) markings on the new batteries with the markings on the underside of battery door.
7. To close the battery door, turn the indented notch clockwise (to the right). You may use the pump key, a coin or your fingers.
8. Press and hold the power button on the right-hand side to turn the pump on.
9. Re-start the CADD Solis pump by pressing the START/STOP button on keypad.
10. When you see “**Start Pump?**” Press “**Yes**” on keypad. Pump will now be running.